

Review of ES18649 rev01, 04-13-16, Eric Rod

HPCAT "Granite Base Plate" review. See marked up drawing ES18649 rev01.

- The height from the top of granite base to the floor should be 917.4mm (36.12").
 - This was called out on our original reference drawings for quote.
 - Leveling wedges should be roughly midrange at the above dimension.
- On granite block, all ¼"-20 inserts should be replaced with 3/8"-16 inserts (per original request).
- On granite block, all 3/8"-16 inserts should be replaced with ½"-13 inserts (per original request).
- Replace all M24x3 lifting inserts with ¾"-10 lifting inserts.
- Length of granite base is not listed (should be 48").
- Some key insert locational dimensions are not listed from reference edge.
- Two insert locational dimensions are referenced to a chamfer and not block edge (small difference).